

# Contents

## 01 Controls and displays

Front panel .....	6
Remote control .....	6
Display .....	8

## 02 Getting started

Home theater sound setup .....	9
Setting the channel levels .....	9
Using the on-screen displays .....	10
Playing discs .....	10
Basic playback controls .....	10
Resume and Last Memory .....	11
DVD-Video disc menus .....	11
Video CD/Super VCD PBC menus .....	11
Listening to the radio .....	12
Improving poor FM reception .....	12
Memorizing stations .....	12
Listening to station presets .....	12
Listening to other sources .....	12
Setting the sleep timer .....	13
Dimming the display .....	13

## 03 Listening to your system

Auto listening mode .....	14
Listening in surround sound .....	14
Using Front Surround .....	14
Listening in stereo .....	15
Listening with headphones .....	15
Using the SFC modes .....	15
Adjusting the bass and treble .....	15
Boosting the bass level .....	15

## 04 Disc playback features

Scanning discs .....	16
Playing in slow motion .....	16
Frame advance/frame reverse .....	16
Playing a JPEG slideshow .....	16
Browsing DVD or Video CD/Super VCD discs with the Disc Navigator .....	17
Browsing WMA, MP3, MPEG-4 AAC, DivX video and JPEG files with the Disc Navigator .....	18
Looping a section of a disc .....	18
Using repeat play .....	18
Using random play .....	19
Creating a program list .....	19
Other functions available from the program menu .....	20
Searching a disc .....	20
Switching subtitles .....	20
Switching language / audio channels .....	20
Zooming the screen .....	21
Switching camera angles .....	21
Displaying disc information .....	21

## 05 USB playback

Using the USB interface .....	22
Basic playback controls .....	22
Scanning files .....	23
Playing a JPEG slideshow .....	23
Browsing files with the Navigator .....	23

## 06 Audio Settings and Video Adjust menus

Audio Settings menu .....	24
Audio DRC .....	24
Video Adjust menu .....	24

## 07 Initial Settings menu

Using the Initial Settings menu .....	25
Video Output settings .....	25
Language settings .....	25
Display settings .....	26
Options settings .....	26
Speakers settings .....	26
Parental Lock .....	26
About DivX® VOD content .....	27
Speaker Distance .....	28

## 08 Other connections

Connecting external antennas .....	29
Connecting auxiliary audio components .....	29
Connecting the S-video output .....	29
Connecting using the component video output .....	30
About progressive scan video .....	30

## 09 Additional information

Disc / content format playback compatibility .....	31
Disc compatibility table .....	31
About DVD+R/DVD+RW compatibility .....	32
About DivX .....	32
About MPEG-4 AAC .....	33
About WMA .....	33
Using and taking care of discs .....	33
DVD Video regions .....	34
Installation and maintenance .....	34
Hints on installation .....	34
Cleaning the pickup lens .....	34
Problems with condensation .....	34
Moving the system unit .....	34
Screen sizes and disc formats .....	35
TV system setting .....	35
Frequency step setting .....	35

